

BOOM TRUCK OPERATOR – STIFF BOOM UNLIMITED TONNAGE

Occupation Description

"Stiff Boom Unlimited Tonnage" operator means a person who operates a truck mounted hydraulic stiff boom crane with capacity over 40 tonnes to perform lifts and hoists, places and secures loads, sets up the crane, takes down the crane and plans lifts and crane procedures.

For detailed information on the scope of knowledge and skills taught and assessed in this program refer to the Program Outline, available on the ITA website.

Pathways to Certification

In BC, an individual can become certified as a Boom Truck Operator – Stiff Boom Unlimited Tonnage by completing the Boom Truck Operator – Stiff Boom Unlimited Tonnage program or by challenging the certification. All crane operators must be registered with the British Columbia Association for Crane Safety (BCACS) prior to applying for ITA apprenticeship registration. Apprenticeship programs are for individuals who have an employer to sponsor them and challenge programs are for individuals who have extensive experience working in the occupation and wish to challenge the certification.

Recommended Education

The following education is recommended for apprentices entering this occupation. These are not prerequisites, but rather a desired level of skill or knowledge that will contribute to success in the industry.

Grade 12 or equivalent

BCACS Registration

BCACS registration is required for all crane operators in British Columbia. Registration forms are available on the BCACS website at www.bcacs.ca.


ITA Registration

Individuals who wish to begin an apprenticeship in this program must register with ITA along with their sponsor. Application forms for all programs are available from the ITA website. Online registration is also available for most programs through the ITA website.

Those who wish to challenge the Boom Truck Operator – Stiff Boom Unlimited Tonnage certification must complete the Boom Truck Operator – Stiff Boom Unlimited Tonnage Challenge Package and submit it to ITA. Challenge applications are assessed for proof of workplace hours and scope of experience prior to acceptance of the individual into the challenge pathway.

Apprenticeship Pathway

This graphic provides an overview of the Boom Truck Operator – Stiff Boom Unlimited Tonnage apprenticeship pathway.



- * Crane-related experience as entered in the operator's BCACS electronic logbook
- † Suggested duration based on 35-hour week

CROSS-PROGRAM CREDITS

Individuals who hold partial credit in a crane program and plan to move to an alternate crane program

Crane Common Core Level 1 Technical Training: Level 1, including ITA Level 1 Standardized Written Exam (Crane Common Core)



	Apprenticeship Program Standards		
Credentials Awarded	 Boom Truck Operator – Stiff Boom Unlimited Tonnage - Certificate of Qualification Boom Truck Operator – Stiff Boom Unlimited Tonnage - Certificate of Apprenticeship 		
ITA Registration Prerequisites	Agreement signed by the Sponsor to sponsor the apprentice		
Completion Requirements	Certification as a Boom Truck Operator – Stiff Boom Unlimited Tonnage is awarded upon successful completion of:		
	Requirement	Level of Achievement Required	
	Technical Training	 Minimum 70% in each level of technical training: Crane Common Core Level 1: 3 weeks* Boom Truck Operator – Stiff Boom Unlimited Tonnage Level 2: 6 weeks* 	
	ITA Level 1 Standardized Written Exam (Crane Common Core)	Minimum 70%	
	ITA Certificate of Qualification Exam	■ Minimum 70%	
	ITA Standardized Practical Assessment	 Pass Note: Successful completion of the ITA Certificate of Qualification Exam is required before attempting the practical assessment 	
	Work-Based Training	 Duration will vary depending upon the individual and the completion of defined competencies 	
	Notification by BCACS that the Sponsor(s) has recommended certification of the apprentice in this trade	 Completed electronic logbook signed off by the Sponsor(s) on all competencies and workplace hours 	
	(*Assuming 35 hours in school per week)		
Program Duration	Duration varies depending on how training is delivered and the type and number of workplace hours that are accumulated.		
	The technical training requirement is typically met through block-release training (full-time, at school) delivered by an ITA-approved training provider. It can also be met through approved alternative training models (e.g., distance education, online, part-time) and/or level challenge where these options are available.		
Challenging a Level	The following levels of technical training can be challenged for advanced placement in this program: Crane Common Core Level 1		



Apprenticeship Program Standards

Cross-Program Credits

Individuals who hold partial credit in a crane program and plan to move to an alternate crane program

Credential

Credit(s) Granted


Crane Common Core Level 1

 Technical Training: Level 1, including ITA Level 1 Standardized Written Exam (Crane Common Core)



Challenge Pathway

This graphic provides an overview of the Boom Truck Operator – Stiff Boom Unlimited Tonnage challenge pathway.



CREDIT FOR PRIOR LEARNING

Individuals who hold the credentials listed below are entitled to receive partial credit toward the completion requirements of this program

None



	Challenge Program Standards		
Credentials Awarded	■ Boom Truck Operator – Stiff Boom Unlimited Tonnage - Certificate of Qualification		
ITA Registration Prerequisites An approved Challenge Application, which includes:			
	 Documented evidence of achievement of the competencies listed in the ITA Boom Truck Operator – Stiff Boom Unlimited Tonnage Challenge Application 		
Credit for Prior Learning	Individuals who hold the credentials listed below are considered to have met, or partially met, the prerequisites for challenging this program:		
	Credential	Credit(s) Granted	
	None	None	
Completion Requirements	Certification as a Boom Truck Operator – Stiff Boom Unlimited Tonnage is upon successful completion of:		
	Requirement	Level of Achievement Required	
	ITA Certificate of Qualification Exam	■ Minimum 70%	
	ITA Standardized Practical Assessment	Pass	
		Note: Successful completion of the ITA Certificate of Qualification Exam is required before attempting the practical assessment	



Supporting Documents

Boom Truck Operator – Stiff Boom Unlimited Tonnage Program Outline (2012) – Defines the full scope of knowledge and skills required to competently perform the occupation in BC. Available from the ITA website: www.itabc.ca.

Boom Truck Operator – Stiff Boom Unlimited Tonnage Getting Ready Guide – Provides information on the level examinations, examination topics and how an individual can prepare for the examination. Available from the ITA website: www.bcacs.ca and from the BCACS website: www.bcacs.ca.

Operator logbook – Crane programs utilize an electronic logbook which is assigned upon registering with the BC Association for Crane Safety (BCACS). All crane operators must be registered with BCACS.

Contacts

The **Industry Training Authority (ITA)** manages B.C.'s industry training and apprenticeship programs. Contact ITA Customer service if you have any questions regarding registration, examinations or certification for this program.

Telephone: 778-328-8700 Fax: 778-328-8701

Toll Free (within BC): 1-866-660-6011 Email: customerservice@itabc.ca

Website: <u>www.itabc.ca</u>

The **BC Association for Crane Safety (BCACS)** sets and manages the industry program standards and the crane operator certification program in British Columbia. BCACS works with industry to identify current and emerging knowledge, skill, and safety requirements for occupations related to this program.

Telephone: 604-336-4699 Fax: 604-336-4510 Email: info@bcacs.ca Website: www.bcacs.ca

Revision History

The standards for this program were reviewed and/or updated on the dates below.

Program Standards Approved: March 2002 Updated: December 2007 Updated: June 2012 Updated: October 2013

Program Profiles are updated regularly. Visit www.itabc.ca for the most current version.